THINK, Interlook rework process



interlook tight protection

Front guide



To remove the front guide with multiple slip joint plier



To Remove the intermediate part



DO NOT SPOIL THE CASING PAINTING DURING THE PROCESS



To remove the interlook with an enab tool and a screwdriver

To control the conformity of the tight protection following indication below



Printed identification COMPLIANT PART



Engraved identification NON COMPLIANT PART

To refit following process M106M277